



ATIMPEX Ltd. 36 Bradley House, LONDON SE16 2DL  
Tel.: 0207 450 5292 E-mail: [support@ledcentre.uk.com](mailto:support@ledcentre.uk.com)

## Installation manual for MR16/12V products

Thank you for shopping from LEDcentre.uk.com

We would like to help your electrician with the installation.

Voltage: DC 12V, stabilised.

Transformers: Please use our Waterproof LED driver/power supply only. To calculate the required output of the LED driver, please use the power consumption details displayed on the product. The total power consumption of MR16/12V LED products connected to the power supply should never be higher than the Wattage of the power supply.

**Please note: Conventional electronic transformers are not suitable for LED lighting.**

The mains supply must always be isolated prior to installation. The overall electrical installation must conform to the relevant regulations.

The LEDcentre does not take any responsibilities for personal injuries or damage of the goods caused by incorrect installation. All installation must be carried out by qualified persons.